

DIY Mobile Home Windows



INSTALLATION INSTRUCTIONS

YOU WILL NEED THE FOLLOWING

1 X HELPER

1 X CORDLESS DRIVER

1 X NYLON FACED HAMMER

FROM OUTSIDE LIFT THE WINDOW INTO THE APERTURE, THE WINDOW IS DESIGNED ODD-LEG STYLE SO AS TO HAVE A 19MM LIP ALL THE WAY AROUND THE OUTSIDE, THIS LIP IS FITTED WITH A 6MM WATERPROOF TAPE SEAL.



ONCE THE WINDOW IS FULLY IN, THE PERSON ON THE INSIDE SHOULD FIT THE INTERNAL TRIM TO THE SEARRTED PART OF THE PROFILE, USING THE NYLON FACED HAMMER THE PERSON SHOULD THEN HAMMER IN THE TRIM, THUS PULLING THE WINDOW IN TIGHT, REPEAT THIS FOR ALL 4 SIDES, ONCE IN IF THE WINDOW OPENS, OPEN THE SASH AND SCREW 2 FIXING SCREWS, 1 PER SIDE THROUGH THE FRICTION STAY (HINGE) WERE A SCREW HOLE IS SHOWING. TAP ON THE 4 MOULDED CORNERS TO LEAVE AN INTERNAL DECORATIVE FINISH.

CLEAN THE UPVC WITH UPVC SOLVENT CLEANER AND THE GLASS WITH GLASS CLEANER.

THE LARGE FRONT WINDOW (NORMALLY FIXED NON OPENING) MAY NEED TO BE UNGLAZED, TO ALLOW YOU TO SCREW IT IN FOR ADDED SAFETY, IF SO THEN THE

EXTERNAL BEADS SHOULD BE REMOVED BY MEANS OF A SCRAPER (PAINT), ONCE OUT THE GLASS CAN BE REMOVED WITH GLASS SUCKERS, THE FRAME CAN THEN BE FITTED AS 1 & 2 ABOVE, SCREWS CAN BE PUT THROUGH THE UPVC FRAME INTO THE CARAVAN TIMBERS VERTICALLY AND HORIZONTALLY. THE GLASS THEN CAN BE REFITTED ON GLASS PACKERS AND BEADS THEN PUSHED AND CLICKED IN.

